


HITACHI

SERVICE MANUAL



TK

No. 4715E

VT-FX614A

US MECHANISM

The VT-FX614A VCR is similar to the previous VT-FX623A. This service manual includes only differences from the VT-FX623A described in the previous VT-FX621A/623A manual (No.4624E). For complete information on the VT-FX614A, also refer to the No. 4624E manual. A US MECHANISM is used for the VT-FX614A mechanical block. For repair and maintenance of the mechanism, refer to the service manual, US MECHANISM (No.4527E).

Manuals to be related to VT-FX614A.

Name of manual	Manual No.
VT-FX621A/FX623A	4624E
US Mechanism	4527E

VHS

This video deck is a VHS type video recorder. For proper operation, only the VHS type cassette must be used.


VCR *Plus*^c
w/Cable Channel
Changer

SPECIFICATIONS AND PARTS ARE SUBJECT TO CHANGE FOR IMPROVEMENT

VIDEO CASSETTE RECORDER

June 1997 Image & Information Media Systems Division, Tokai

1. LUMA/CHROMA, LINEAR AUDIO [MAS] SECTION



After Change	Before Change
Page 6-16 (4-D)	
QF852 ICP-N15 600mA CIRCUIT PROTECT	QF852 ICP-N15 600mA CIRCUIT PROTECT

This parts list only includes the components which are different from the VT-FX623A.

2. ELECTRICAL PARTS LIST

SYMBOL NO	P-NO	DESCRIPTION	SYMBOL NO	P-NO	DESCRIPTION
102	PH15532	PANEL, FRONT (HEPM)	C0252	0209943	CERAMIC CHIP 120PF+-5% 50V
803	HL10632	REMOTE HAND SET (VT-RM614A) (HEPM)	C0258	0209933	CERAMIC CHIP 18PF+-5% 50V
			C0260	0209931	CERAMIC CHIP 12PF+-5% 50V
			C0877	1143002	CERAMIC DISC 100PF 500V
			R0257	0700055	CARBON FILM 12KOHM+-5% 1/8W
			D0857	CH10462S	DIODE S3L20U
			IC1801	CS10351	PWM ASSY HTS7337

HITACHI